

Message Sign Solutions (LED)

Healthcare Lighting's Alert message sign can be surface or canopy mounted. Pick the desired message legend from our list of standards or indicate one of your own. The ultra low consumption Alert is designed to last the lifetime of the building with virtually no maintenance. It meets the requirements of UL 924 and DOE Energy Star Program.

Upon power failure, solid-state emergency battery option transfers operation to the internal nickel cadmium battery. The battery is on a constant current, 24 hour recharge. It includes a board mounted pilot light and face activated switch.

(SURFACE & CANOPY MOUNT)



FEATURES



Sign faces are easily removed for installation and service. This allows simple access to the LED strip, transformer and quick disconnect. No tools are required to remove sign legend.



Universal ceiling and wall canopy plates allow easy installation for both ceiling and wall mounting.



Specifications

(Specifications subject to change, consult web site for any revisions)

- Construction:** Heavy gauge steel housing frame and stenciled face plate.
- Sign Face:** High grade thermoplastic color shield in red, green, or blue corresponding to LED colors.
- Electrical:** Internally mounted universal 120-277v transformer driving an LED strip. A polarized plug, with quick disconnect is provided between LED board and transformer for easy installation and maintenance.
- LED's:** Top mounted, downward facing LED board illuminates the corresponding color legend; LED colors are available in red, green or blue; accent down light on bottom edge is standard, (lamps included).
- Switching:** Line voltage switching by others.
- Mounting:** Single face surface wall mount; single or double face ceiling or wall mount with canopy.
- Standard Finish:** Entire fixture is polyester powder coated **gloss white**.
- CA OSHPD:** California Office of Statewide Health Planning and Development. Seismic mounting pre-approval status: (calculations and pre-approval not required).
- Listings:** Meets the requirements of UL 924 and the DOE Energy Star program.



ORDERING INFORMATION

Example: HSG303-XIU-R-EM

Series

- HSG301** Surface mount with single side legend
- HSG302** Canopy mount with single side legend
- HSG303** Canopy mount with double side legend

Sign Legend

- | | |
|-----------------------------|---|
| DRIU DARKROOM IN USE | BO BEAM ON |
| DNE DO NOT ENTER | BR BEAM READY |
| IU IN USE | LIU LASER IN USE |
| XIU X-RAY IN USE | ARA AREA OF RESCUE ASSISTANCE |
| XO X-RAY ON | ARAW AREA OF RESCUE ASSISTANCE (with wheelchair graphic) |
| MIU MRI IN USE | AOR AREA OF REFUGE |
| EX EXIT | SW SPECIAL WORDING |

Legend & LED Color

- G** Green
- R** Red
- B** Blue

Options

- EM** Emergency battery back up

